

Bluelab Commercial Truncheon™ Troubleshooting

Problem

Corrective Action

Commercial Truncheon turns off before reading taken.

Take out of solution for 3-5 seconds. Dip in solution again and take reading.

Commercial Truncheon not lighting up when dipped in solution.

Clean the probe (see page 2 of Commercial Truncheon Manual). If this is unsuccessful, replace batteries (page 2 of Commercial Truncheon Manual).
“Do not use rechargeable batteries.”

Commercial Truncheon gives low readings.

Clean the probe (see page 2 of Commercial Truncheon Manual).
Ensure unscented cleaner is used, such as plain ‘Jif’/‘Soft Scrub’/‘Liquid Vim’.